

SparkA /	9	1	SparkA / Idle
SparkB //	10	2	Fuel pump rel.
*SparkC ///	11	3	Inj. driver 2
*SparkD ///	12	4	Inj. driver 2
X14	13	5	Inj. driver 1
X13 ///	14	6	Inj. driver 1
X12 //	15	7	GND
X11 /	16	8	GND

Connector B

12V+	8	1	ground
TPS Vref 5V+	9	2	VR-
Spare 4	10	3	VR+
Spare 3	11	4	O2
Spare 2	12	5	TPS
Spare 1	13	6	CLT
grd sensors	14	7	IAT

Connector A

